




Supplied with Lithium battery, Charging station with fixings, red cone and an AC mains charger with 4 country plug adaptors.

Mounting the charging station to wall

- Push the button, and push the wall plate down to slide it off the charging station.




- Fix the wall plate to the wall using fixings provided
- Slide the wall station onto the wall plate.

Charging the Flashlight

- Insert battery in flashlight
- Plug the charger into charging station and connect to a AC power supply
- Press the ON button on the wall station
- Place the flashlight into wall station making sure the two pin connectors lineup between flashlight and charging station. The red LED will light up when good connection is made.
- When the battery is fully charged, the LED on the charger will turn green.



Power/light mode tail cap switch



EMERGENCY LEDS ON THE CHARGING STATION



- If there is a power cut when the flashlight is mounted in the charging station the 6 white leds will turn on so the flashlight can be easily found in the dark. The switch on the charging station must be turned 'ON' for the function to work. User can choose to switch this function 'ON' or 'OFF'.



For use in vehicles:

Optional 12/24V Vehicle Charger
Product code: 5838201



THE WILL-BURT COMPANY
401 Collins Blvd., Orrville, OH USA 44667
Telephone: +1 330 684 4000
Email: info@willburt.com

All NightSearcher products have a 3-year standard warranty on all manufacturing defects and 1-year warranty on all rechargeable batteries from the date of purchase.



Product weight (g)	280g
Product size (mm)	120x190X70mm
NS Part No.	5838101