





**NOTE:**

- 1. APPLY RTV #739 OR EQUAL TO ALL OPEN HOLES
- 2. SEE WIRING DIAGRAM WD-46276 FOR WIRING DETAILS
- 3. SET LIGHT BARS HOME POSITION PARALLEL TO BASE PLATE WHEN STOWED
- 4. APPLY LOCTITE #242 OR EQUAL TO ALL THREADS UNLESS OTHERWISE NOTED
- 5. APPLY A COAT OF SILICONE GREASE TO RCP MOTOR BORES PRIOR TO SHIFTS BEING INSTALLED

BOM			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	4627603	BASE ASSEMBLY NSP
2	1	4742501	RCP ASSEMBLY NSP STD
3	1	4746309	KIT, LIGHT OPT. 4500W (6) X 750 220V
4	1	4807801	KIT, SHIPPING NSP (NOT SHOWN)
5	1	4706701	NSP LABEL KIT (NOT SHOWN)

MATERIAL		UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES.		PROPRIETARY AND CONFIDENTIAL		WILL-BURT AN EMPLOYEE OWNED COMPANY ORRVILLE, OH	
FINISH		TOLERANCES ON:		THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF THE WILL-BURT COMPANY ANY REPRODUCTION IN PART OR WHOLE WITHOUT THE WRITTEN PERMISSION OF THE WILL-BURT COMPANY IS PROHIBITED.		TITLE	
APPROX. WT:161.4 lbmass		DIMENSIONS ± 0.005		APPROVALS		SIZE	DWG NO
THIRD ANGLE PROJECTION		ANGLES ± 1°		DRAWN		B	721063013
		1. ALL ANGLES 90°		CHECKED		PN:	721063013
		2. ALL INSIDE EDGES TO HAVE .005" TO .035" FILLETS.				SHEET 2 OF 2	
		3. ALL OUTSIDE EDGES TO HAVE .005" TO .015" CHAMFER OR RADIUS.					
		125√ ON ALL MACHINED SURFACES					